

Use ibex

To have a easier life 😊

\$ which conda

check the information of conda which is being used

\$ conda create --name **py3** python=3.7

create a new virtual env with python of version 3.7

\$ conda activate py3

activate one specific env according to the name

\$ conda deactivate

deactivate an activate env

\$ conda env list

get a list of all envs available

[conda cheatsheet](#)

Run remote Jupyter notebook on local browser

First—on remote server

- **\$ ssh [username@vlogin.ibex.kaust.edu.sa](#)**
 - enter the password; login in remote server successfully;
 - create a new conda env and ensure the jupyter notebook is installed;
 - activate the the conda env you want to use.
- **\$ jupyter notebook**
 - open nb and check the port, for example, **8889**
 - ctrl+c to kill the running nb
- **\$ nohup jupyter notebook --no-browser --port=8889 > log.notebook 2>&1 &**

Run remote Jupyter notebook on local browser

Second—set password

- ***\$ jupyter notebook --generate--config***
 - create the Jupyter folder, and notebook configuration file, *jupyter_notebook_config.py*, in this folder.
- ***\$ jupyter notebook password***
 - enter and verify password;
 - password will be written to *jupyter_notebook_config.json*, which in the same directory with *jupyter_notebook_config.py*
- ***\$ rm jupyter_notebook_config.py***
 - this file could be delete directly.

Run remote Jupyter notebook on local browser

Then—on local laptop

- `$ ssh -N -f -L localhost:8882:localhost:8889 username@vlogin.ibex.kaust.edu.sa`
 - the first port is used on your localhost and second port should be consistent with the port where the nb is running on the remote server;
 - enter the password correctly;
 - type **localhost:8882** to the URL blank region of the local browser and enter;
 - enter the password and then you are able to use nb.

Useful tutorials

- [running jupyter notebook on remote servers](#)
- [jupyter notebook official document](#)